




---

 PRODUCT-DETAILS

# 3BSE004939R1012

## SDCS-PIN-48-SD; SDCS-PIN48-SD PULSE TRANSFORMER BOARD

"No longer for sale" replaced by




---

**General Information**

Product ID	3BSE004939R1012
ABB Type Designation	SDCS-PIN-48-SD
Catalog Description	SDCS-PIN-48-SD; SDCS-PIN48-SD PULSE TRANSFORMER BOARD

---

**Ordering**

Country of Origin	Thailand (TH)
Customs Tariff Number	85049090
Invoice Description	SDCS-PIN48-SD PULSE TRANSFORMER BOARD
Made To Order	No
Minimum Order Quantity	1 piece
Order Multiple	1 piece
Quote Only	No
Selling Unit of Measure	piece

---

**Dimensions**

Product Net Weight	0.328 kg
Package Level 1 Units	1 piece

**Technical**

Frame Size

Spare Parts

**Classifications**

UNSPSC

39122004

**Environmental**

WEEE Category

Product Not in WEEE Scope

**Additional Information**

Product Name

SDCS-PIN48-SD PULSE TRANSFORMER BOA

**Where Used (as a spare part for "Products")**

Identifier	Description	Quantity	Unit Of Measure
DCS800-S01-0900-06	No Description Available	1	piece
DCS800-S01-0900-07	No Description Available	1	piece
DCS800-S01-1200-04	No Description Available	1	piece
DCS800-S01-1200-05	No Description Available	1	piece
DCS800-S01-1500-04	No Description Available	1	piece
DCS800-S01-1500-05	No Description Available	1	piece
DCS800-S01-1500-06	No Description Available	1	piece
DCS800-S01-1500-07	No Description Available	1	piece
DCS800-S01-1900-08	No Description Available	1	piece
DCS800-S01-2000-04	No Description Available	1	piece
DCS800-S01-2000-05	No Description Available	1	piece
DCS800-S01-2000-06	No Description Available	1	piece
DCS800-S01-2000-07	No Description Available	1	piece
DCS800-S01-2050-05	No Description Available	1	piece
DCS800-S01-2050-06	No Description Available	1	piece
DCS800-S01-2050-07	No Description Available	1	piece
DCS800-S01-2500-04	No Description Available	1	piece
DCS800-S01-2500-05	No Description Available	1	piece
DCS800-S01-2500-06	No Description Available	1	piece
DCS800-S01-2500-07	No Description Available	1	piece
DCS800-S01-2500-08	No Description Available	1	piece
DCS800-S01-3000-04	No Description Available	1	piece
DCS800-S01-3000-05	No Description Available	1	piece
DCS800-S01-3000-06	No Description Available	1	piece
DCS800-S01-3000-07	No Description Available	1	piece
DCS800-S01-3000-08	No Description Available	1	piece
DCS800-S02-0900-06	No Description Available	1	piece

DCS800-S02-0900-07	No Description Available	1	piece
DCS800-S02-1200-04	No Description Available	1	piece
DCS800-S02-1200-05	No Description Available	1	piece
DCS800-S02-1500-04	No Description Available	1	piece
DCS800-S02-1500-05	No Description Available	1	piece
DCS800-S02-1500-06	No Description Available	1	piece
DCS800-S02-1500-07	No Description Available	1	piece
DCS800-S02-1900-08	No Description Available	1	piece
DCS800-S02-2000-04	No Description Available	1	piece
DCS800-S02-2000-05	No Description Available	1	piece
DCS800-S02-2050-05	No Description Available	1	piece
DCS800-S02-2050-06	No Description Available	1	piece
DCS800-S02-2050-07	No Description Available	1	piece
DCS800-S01-2050-10R	No Description Available	1	piece
DCS800-S01-2600-10R	No Description Available	1	piece
DCS800-S01-3300-04R	No Description Available	1	piece
DCS800-S01-3300-05R	No Description Available	1	piece
DCS800-S01-3300-06R	No Description Available	1	piece
DCS800-S01-3300-07R	No Description Available	1	piece
DCS800-S01-3300-08R	No Description Available	1	piece
DCS800-S01-3300-10R	No Description Available	1	piece
DCS800-S01-4000-04R	No Description Available	1	piece
DCS800-S01-4000-05R	No Description Available	1	piece
DCS800-S01-4000-06R	No Description Available	1	piece
DCS800-S01-4000-07R	No Description Available	1	piece
DCS800-S01-4000-08R	No Description Available	1	piece
DCS800-S01-4000-10R	No Description Available	1	piece
DCS800-S01-4800-06R	No Description Available	1	piece
DCS800-S01-4800-07R	No Description Available	1	piece
DCS800-S01-4800-08R	No Description Available	1	piece
DCS800-S01-5200-04R	No Description Available	1	piece
DCS800-S01-5200-05R	No Description Available	1	piece
DCS800-S02-2050-10R	No Description Available	1	piece
DCS800-S02-2600-10R	No Description Available	1	piece
DCS800-S02-3300-04R	No Description Available	1	piece
DCS800-S02-3300-05R	No Description Available	1	piece
DCS800-S02-3300-06R	No Description Available	1	piece
DCS800-S02-3300-07R	No Description Available	1	piece
DCS800-S02-3300-08R	No Description Available	1	piece
DCS800-S02-3300-10R	No Description Available	1	piece
DCS800-S02-4000-04R	No Description Available	1	piece
DCS800-S02-4000-05R	No Description Available	1	piece
DCS800-S02-4000-06R	No Description Available	1	piece
DCS800-S02-4000-07R	No Description Available	1	piece
DCS800-S02-4000-08R	No Description Available	1	piece
DCS800-S02-4000-10R	No Description Available	1	piece
DCS800-S02-4800-06R	No Description Available	1	piece
DCS800-S02-4800-07R	No Description Available	1	piece
DCS800-S02-4800-08R	No Description Available	1	piece
DCS800-S02-5200-04R	No Description Available	1	piece
DCS800-S02-5200-05R	No Description Available	1	piece
DCS800-S01-2050-10L	No Description Available	1	piece
DCS800-S01-2600-10L	No Description Available	1	piece
DCS800-S01-3300-04L	No Description Available	1	piece
DCS800-S01-3300-05L	No Description Available	1	piece
DCS800-S01-3300-06L	No Description Available	1	piece
DCS800-S01-3300-07L	No Description Available	1	piece
DCS800-S01-3300-08L	No Description Available	1	piece

DCS800-S01-3300-10L	No Description Available	1	piece
DCS800-S01-4000-04L	No Description Available	1	piece
DCS800-S01-4000-05L	No Description Available	1	piece
DCS800-S01-4000-06L	No Description Available	1	piece
DCS800-S01-4000-07L	No Description Available	1	piece
DCS800-S01-4000-08L	No Description Available	1	piece
DCS800-S01-4000-10L	No Description Available	1	piece
DCS800-S01-4800-06L	No Description Available	1	piece
DCS800-S01-4800-07L	No Description Available	1	piece
DCS800-S01-4800-08L	No Description Available	1	piece
DCS800-S01-5200-04L	No Description Available	1	piece
DCS800-S01-5200-05L	No Description Available	1	piece
DCS800-S02-2050-10L	No Description Available	1	piece
DCS800-S02-2600-10L	No Description Available	1	piece
DCS800-S02-3300-04L	No Description Available	1	piece
DCS800-S02-3300-05L	No Description Available	1	piece
DCS800-S02-3300-06L	No Description Available	1	piece
DCS800-S02-3300-07L	No Description Available	1	piece
DCS800-S02-3300-08L	No Description Available	1	piece
DCS800-S02-3300-10L	No Description Available	1	piece
DCS800-S02-4000-04L	No Description Available	1	piece
DCS800-S02-4000-05L	No Description Available	1	piece
DCS800-S02-4000-06L	No Description Available	1	piece
DCS800-S02-4000-07L	No Description Available	1	piece
DCS800-S02-4000-08L	No Description Available	1	piece
DCS800-S02-4000-10L	No Description Available	1	piece
DCS800-S02-4800-06L	No Description Available	1	piece
DCS800-S02-4800-07L	No Description Available	1	piece
DCS800-S02-4800-08L	No Description Available	1	piece
DCS800-S02-5200-04L	No Description Available	1	piece
DCS800-S02-5200-05L	No Description Available	1	piece
DCS800-S01-0900-06a	No Description Available	1	piece
DCS800-S01-0900-06-b	No Description Available	1	piece
DCS800-S01-0900-07a	No Description Available	1	piece
DCS800-S01-0900-07-b	No Description Available	1	piece
DCS800-S01-1200-04a	No Description Available	1	piece
DCS800-S01-1200-04-b	No Description Available	1	piece
DCS800-S01-1200-05a	No Description Available	1	piece
DCS800-S01-1200-05-b	No Description Available	1	piece
DCS800-S01-1500-04-b	No Description Available	1	piece
DCS800-S01-1500-05-b	No Description Available	1	piece
DCS800-S01-1500-06-b	No Description Available	1	piece
DCS800-S01-1500-07-b	No Description Available	1	piece
DCS800-S01-1900-08a	No Description Available	1	piece
DCS800-S01-1900-08-b	No Description Available	1	piece
DCS800-S01-2000-04-b	No Description Available	1	piece
DCS800-S01-2000-05-b	No Description Available	1	piece
DCS800-S01-2000-06-b	No Description Available	1	piece
DCS800-S01-2000-07-b	No Description Available	1	piece
DCS800-S01-2050-05a	No Description Available	1	piece
DCS800-S01-2050-05-b	No Description Available	1	piece
DCS800-S01-2050-06a	No Description Available	1	piece
DCS800-S01-2050-06-b	No Description Available	1	piece
DCS800-S01-2050-07a	No Description Available	1	piece
DCS800-S01-2050-07-b	No Description Available	1	piece
DCS800-S01-2050-10-b	No Description Available	1	piece
DCS800-S01-2500-04-b	No Description Available	1	piece
DCS800-S01-2500-05-b	No Description Available	1	piece

DCS800-S01-2500-06-b	No Description Available	1	piece
DCS800-S01-2500-07-b	No Description Available	1	piece
DCS800-S01-2500-08-b	No Description Available	1	piece
DCS800-S01-2600-10-b	No Description Available	1	piece
DCS800-S01-3000-04-b	No Description Available	1	piece
DCS800-S01-3000-05-b	No Description Available	1	piece
DCS800-S01-3000-06-b	No Description Available	1	piece
DCS800-S01-3000-07-b	No Description Available	1	piece
DCS800-S01-3000-08-b	No Description Available	1	piece
DCS800-S01-3300-04-b	No Description Available	1	piece
DCS800-S01-3300-05-b	No Description Available	1	piece
DCS800-S01-3300-06-b	No Description Available	1	piece
DCS800-S01-3300-07-b	No Description Available	1	piece
DCS800-S01-3300-08-b	No Description Available	1	piece
DCS800-S01-3300-10-b	No Description Available	1	piece
DCS800-S01-4000-04-b	No Description Available	1	piece
DCS800-S01-4000-05-b	No Description Available	1	piece
DCS800-S01-4000-06-b	No Description Available	1	piece
DCS800-S01-4000-07-b	No Description Available	1	piece
DCS800-S01-4000-08-b	No Description Available	1	piece
DCS800-S01-4000-10-b	No Description Available	1	piece
DCS800-S01-4800-06-b	No Description Available	1	piece
DCS800-S01-4800-07-b	No Description Available	1	piece
DCS800-S01-4800-08-b	No Description Available	1	piece
DCS800-S01-5200-04-b	No Description Available	1	piece
DCS800-S01-5200-05-b	No Description Available	1	piece
DCS800-S02-0900-06a	No Description Available	1	piece
DCS800-S02-0900-06-b	No Description Available	1	piece
DCS800-S02-0900-07a	No Description Available	1	piece
DCS800-S02-0900-07-b	No Description Available	1	piece
DCS800-S02-1200-04a	No Description Available	1	piece
DCS800-S02-1200-04-b	No Description Available	1	piece
DCS800-S02-1200-05a	No Description Available	1	piece
DCS800-S02-1200-05-b	No Description Available	1	piece
DCS800-S02-1500-04-b	No Description Available	1	piece
DCS800-S02-1500-05-b	No Description Available	1	piece
DCS800-S02-1500-06-b	No Description Available	1	piece
DCS800-S02-1500-07-b	No Description Available	1	piece
DCS800-S02-1900-08a	No Description Available	1	piece
DCS800-S02-1900-08-b	No Description Available	1	piece
DCS800-S02-2000-04-b	No Description Available	1	piece
DCS800-S02-2000-05-b	No Description Available	1	piece
DCS800-S02-2050-05a	No Description Available	1	piece
DCS800-S02-2050-05-b	No Description Available	1	piece
DCS800-S02-2050-06a	No Description Available	1	piece
DCS800-S02-2050-06-b	No Description Available	1	piece
DCS800-S02-2050-07a	No Description Available	1	piece
DCS800-S02-2050-07-b	No Description Available	1	piece
DCS800-S02-2050-10-b	No Description Available	1	piece
DCS800-S02-2600-10-b	No Description Available	1	piece
DCS800-S02-3300-04-b	No Description Available	1	piece
DCS800-S02-3300-05-b	No Description Available	1	piece
DCS800-S02-3300-06-b	No Description Available	1	piece
DCS800-S02-3300-07-b	No Description Available	1	piece
DCS800-S02-3300-08-b	No Description Available	1	piece
DCS800-S02-3300-10-b	No Description Available	1	piece
DCS800-S02-4000-04-b	No Description Available	1	piece
DCS800-S02-4000-05-b	No Description Available	1	piece

DCS800-S02-4000-06-b	No Description Available	1	piece
DCS800-S02-4000-07-b	No Description Available	1	piece
DCS800-S02-4000-08-b	No Description Available	1	piece
DCS800-S02-4000-10-b	No Description Available	1	piece
DCS800-S02-4800-06-b	No Description Available	1	piece
DCS800-S02-4800-07-b	No Description Available	1	piece
DCS800-S02-4800-08-b	No Description Available	1	piece
DCS800-S02-5200-04-b	No Description Available	1	piece
DCS800-S02-5200-05-b	No Description Available	1	piece

### Product specific part data

Product	Category	Drive Part Category
DCS800-S01-0900-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1900-08	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-08	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-08	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1900-08	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2000-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2000-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-10R	DCS800-S	Boards, Control Units, Power Supplies



<u>Product</u>	<u>Category</u>	<u>Drive Part Category</u>
DCS800-S02-2600-10L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-04L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-05L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-06L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-07L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-08L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-10L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-04L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-05L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-06L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-07L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-08L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-10L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-06L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-07L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-08L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-5200-04L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-5200-05L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-06a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-07a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-04a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-05a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1900-08a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1900-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-05a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-06a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-07a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2600-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-06-b	DCS800-S	Boards, Control Units, Power Supplies



Product	Category	Drive Part Category
DCS800-S01-3300-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4800-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4800-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4800-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-5200-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-5200-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-06a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-07a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-04a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-05a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1900-08a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1900-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-05a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-06a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-07a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2600-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-5200-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-5200-05-b	DCS800-S	Boards, Control Units, Power Supplies

---

## Categories

---

Drives → DC Drives → Industrial Drives → Modules → DCS800-S

